

DIPHANO



Alexa

COLLECTION SHEET



Stackable. Foldable. Comfortable. With a playful Batyline® finishing, the collection offers a welcome variety to any setting. Our Alexa chairs have everything in store to create perfect outdoor pleasure. Alexa's aluminium frame in lava and white combines beautifully with the natural teak top in the extendable, round or bistro tables. Trespa® tops are another option for your demanding projects, guaranteeing easy maintenance and perfect durability.








collection overview


dining armchair

optional teak armrest



folding director's chair

optional teak armrest



barstool 77h

optional teak armrest



barstool 62h

optional teak armrest




folding beach chair




lounger



extendable table 220-280x96




extendable table 160-220x96



round dining table 148xR



high bistro table H



counter bistro table M




bistro table D



technical information

MATERIALS & COLOURS


frame: pca | fabric: textylene (FDF)



frame: pca | table top: teak (26mm/1.02")



frame: pca | table top: Trespa® (13mm/0.51")




frame: pca | table top: ceramic (6mm/0.24")




OPTIONS

cushion set for loungers



FEATURES





maintenance

POWDERCOATED ALUMINIUM

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

BATYLINE® / TEXTYLENE

Easy to clean with water or specific Batyline® cleaner. Avoid the use of abrasive products and high pressure cleaning.



NATURAL TEAK

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth. If the teak is 100% dry and free of dust, you can apply our Teak stain protector to make it repellent to water and moisture. Avoid the use of abrasive products and solvents and high pressure cleaning.



Teak stain protector

Saturates teak to make it repellent to water and moisture. Helps to prevent stains (e.g. wine stains, barbecue stains...). Easy to apply. Transparent finishing.

TRESPA® (HPL)

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution or Trespa® cleaner. Rinse thoroughly and pat dry with a cloth.

CERAMIC

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution or Ceramic cleaner. Rinse thoroughly and pat dry with a cloth.



Glass, ceramic, Trespa® cleaner & polisher

Makes hard surfaces repellent to water, moisture and dirt. Cleans and removes stains without scratching using the included cloth.

DIPHANO

OUTDOOR FURNITURE

www.diphano.com

Textielstraat 4 - 8790 Waregem - Belgium
Tel. +32 (0)56 980 008 - info@diphano.com